


DISCLAIMER:

The installation, maintenance, or removal of an antenna requires qualified, experienced personnel. You must refer to the appropriate local safety codes and ensure proper electrical and electromagnetic compatibility before proceeding with the installation. All local codes shall take precedence over information in this document. Antenna systems should be inspected once a year by qualified personnel to verify proper installation, maintenance, and condition of equipment. Communication Components Antennas Inc. disclaims any liability or responsibility for the results of improper or unsafe installation.





Step Task

The Mounting Kit is intended for antennas with a pitch of 870mm between hinge brackets. It will provide mechanical tilt capability of 0°-20°, and azimuth swiveling of ±30°. The Fixed Bracket only provides swiveling, while the Adjustable Bracket provides tilt and swiveling. The Brackets will arrive assembled for the Downtilt Setup, but the hardware will not be torqued.








Fig. 2: Swiveling MDT Adjustable Bracket BOM

ITEM	QTY	DESCRIPTION	ITEM	QTY	DESCRIPTION
1	6	SCREW, HEX, CAP, M10X1.5, 25L, ISO 4017, SS A4-70, NYLON PATCH	11	10	NUT, HEX, M8-1.25, SS, DIN 934, 13MM HEX
2	1	MAST BRACKET, SINGLE HINGE, ADJUSTABLE, MBK-19	12	2	WASHER, M4, 4.3ID, 90D, 0.8TH, SS, DIN 125, ISO 7089
3	1	LATCH, DOWNTILT BOLT, MBK-19	13	2	NUT, HEX, M4-0.7, NYL LK, SS
4	1	BOLT, DOWNTILT BRACKET, MBK-19	14	5	WASHER, FL, M8, ISO 7093, A2 SS, OVERSIZE
5	1	BRACKET, SWIVEL, JOINT, FLANGED, MBK-19	15	2	THREADEDE ROD, M12X1.75, 300L, DIN 976, SS A2-70
6	1	MAST BRACKET, ADJUSTABLE, REAR, MBK-30	16	8	NUT, HEX, M12X1.75, DIN 934, SS A4-70, 19MM HEX
7	1	MAST BRACKET, ADJUSTABLE, FRONT, MBK-30	17	6	WASHER, FLAT, M12, 37 OD, MIN 2.3 THK, DIN 9021, SS A2-70
8	1	MAST BRACKET, CLAMP, A, MBK-30	18	7	WASHER, FLAT, M10, 30 OD, MIN 2.3 THK, DIN 9021, SS A2-70
9	1	MAST BRACKET, CLAMP, B, MBK-30	19	4	WASHER, SPLIT LOCK, M12, DIN 127B, STEEL, SS A2-70
10	2	NUT, HEX, M10-1.5, DIN 934, 18-8 SS, 17MM HEX			








Step Task


2 Attach the Fixed Bracket by separating one Clamp Bracket from the assembly, by removing some of the associated hardware (see Fig. 3). Place the Bracket on the mast at the correct height in the orientation shown, and also pointing in the desired direction as shown in Fig. 3. Reinstall the Clamp Bracket and the associated hardware. Adjust the M12 threaded rods to balance the protrusion on either side and tighten the M12 nuts to a torque of 54±2.5 N-M (40±2 ft-lbs.). Then tighten all eight M8 nuts (on the underside) to a torque of 9.5±0.5 N-M (7.0±0.5 ft-lb.)

Step Task


3 Attach the Adjustable Bracket by separating one Clamp Bracket from the assembly, by removing some of the associated hardware (see Fig. 4). Place the Bracket on the mast in the orientation shown in Fig. 5, at a distance of 870mm from the Fixed Bracket (depends on tilt direction) and also pointing in the same direction as shown in Fig. 6. Reinstall the Clamp Bracket and associated hardware. Adjust the M12 threaded rods to balance the protrusion on either side and tighten the M12 nuts to a torque of 54±2.5 N-M (40±2 ft-lbs.). Then tighten all eight M8 nuts (on the underside) to a torque of 9.5±0.5 N-M (7.0±0.5 ft-lb.)
















Step	Task
4	Install the antenna/radio assembly on to both the Fixed Bracket using 2 pcs. each of the M10 hardware, and the Adjustable Bracket using 2 pcs. each of the M10 hardware as shown in Fig. 7. Torque M10 hardware to 25±1.5 N-M (18.5±1.5 ft-lbs.). If further alignment is required loosen the M12 hardware holding the mast brackets in place and adjust the alignment of the antenna/radio assembly in the direction specified by the site engineer. The
	orientation of the Antenna is normal to the sector unless specifically
	required otherwise.


Step	Task
5	Once properly aligned torque M12 clamp hardware to 54±2.5 N-M (40±2 ft-lbs.).
6	Completed installation with 0° MDT (Mechanical Tilt) should appear as shown in Fig. 8.




















Step Task


Install the antenna/radio assembly on to both the Fixed Bracket using 2 pcs. each of the M10 hardware, and the Adjustable Bracket using 2 pcs. each of the M10 hardware as shown in Fig. 12. Torque M10 hardware to 25±1.5 N-M (18.5±1.5 ft-lbs.). If further alignment is required loosen the M12 hardware holding the mast brackets in place and adjust the alignment of the antenna/radio assembly in the direction specified by the site engineer. The orientation of the Antenna is normal to the sector unless specifically required otherwise.

Step Task

- 5 Once properly aligned torque M12 clamp hardware to 54±2.5 N-M (40±2 ft-lbs.).
- 6 Completed installation with 0° MDT (Mechanical Tilt) should appear as shown in Fig. 13.









Step Task

7 At the 0° MDT (Mechanical Tilt) position, loosen all fasteners labeled 'A', on both sides of the brackets (Fig. 14).

- Step Task
- 8 Loosen two nuts labeled 'B', slide back the latch 'C', support the antenna and remove the tilt bolt 'D' (Fig. 14).
- Allow the antenna to move such that the hole designated '8' (8° MDT) lines up with the mating hole immediately behind (Fig. 16).
- 10 Insert the tilt bolt all the way, slide the latch up to engage with the tilt bolt (Fig. 16), and tighten the two nuts to a torque of 2.5±0.2 N-M (2.0±0.2 ft-lbs.). Then tighten the fasteners loosened in step 7 to a torque of 25.0±1.5 N-M (18.5±1.5 ft-lbs.).







Step Task

To adjust the azimuth direction, loosen the four M10 nuts labeled "E," and the four M8 nuts labeled "F." Simply rotate the antenna to the desired direction and tighten the four M8 nuts to a torque of 9.5±0.5 N-M (7.0±0.5 ft-lbs.). Then tighten the four M10 nuts to a torque of 25.0±1.5 N-M (18.5±1.5 ft-lbs.). This can be done at any MDT setting.