


# BSA33R-U5CA

## (Type 17 RET Configuration Only)

### Element arrays as viewed from rear of antenna



### RET placement as view from rear of antenna


Top of antenna

All Right Beams



MM.1

All Left Beams



MM.2

Array	Ports	Freq (MHz)	Ports controlled by common RET	AISG RET UID
B1	1, 2	1710-1880	1, 2, 3, 4, 9,10,11,12 (Left Beams)	C1xxxxxxMM.2
B1	3, 4	1710-1880		
Y1	9, 10	2300-2400		
Y1	11, 12	2300-2400		
B2	5, 6	1710-1880	5, 6, 7, 8, 13,14,15,16 (Right Beams)	C1xxxxxxMM.1
B2	7, 8	1710-1880		
Y2	13, 14	2300-2400		
Y2	15, 16	2300-2400		