


BSA33R-U6AA (Type 1 RET Configuration Only)


Element arrays as viewed from rear of antenna




RET placement as view from rear of antenna

Top of antenna

1695-2400
Ports
1, 2, 3, 4
(YTL & YBL)
Left



1695-2400
Ports
5, 6, 7, 8
(YTR & YBR)
Right



Array	Ports	Freq (MHz)	Ports controlled by common RET
YTL	1, 2	1695-2400	1, 2, 3, 4
YBL	3, 4	1695-2400	
YTR	5, 6	1695-2400	5, 6, 7, 8
YBR	7, 8	1695-2400	