


HBSA33R-GU6AA (Type 1 RET Configuration Only)


Element arrays as viewed from rear of antenna

Array	Ports	Freq (MHz)	Ports controlled by common RET
R1	1, 2	617-746	1, 2
YTL	3, 4	1695-2400	3, 4, 5, 6
YBL	5, 6	1695-2400	
YTR	7, 8	1695-2400	7, 8, 9, 10
YBR	9, 10	1695-2400	





**RET placement
as viewed from rear
of antenna**

Top of antenna



**617-746
Ports 1 & 2
(R1)**

**1695-2400
Ports 3, 4, 5 & 6
(YTL & YBL)**



**1695-2400
Ports 7, 8, 9 & 10
(YTR & YBR)**