


TPA45R-GU6AA


(Type 1 RET Configuration Only)

Element arrays as viewed from rear of antenna


Array	Ports	Freq (MHz)	Ports controlled by common RET
RT	1, 2	614-806	1, 2, 3, 4
RB	3, 4	614-806	
YTL	5, 6	1695-2400	5, 6, 9, 10
YTR	9, 10	1695-2400	
YBL	7, 8	1695-2400	7, 8, 11, 12
YBR	11, 12	1695-2400	




RET placement as viewed from rear of antenna
Top of antenna



1695-2400
Ports 5, 6, 9 & 10
(YTL & YTR)



614-806
Ports 1, 2, 3 & 4
(RT & RB)



1695-2400
Ports 7, 8, 11 & 12
(YBL & YBR)