QPA33R-E5A
# (Type 1 RET Configuration Only)

Element arrays as viewed from rear of antenna

RET placement as viewed from rear of antenna

Top of antenna

YL   YR

1695-2690
Ports 1, 2, 3 & 4
(YL & YR)

Array	Ports	Freq (MHz)	Ports controlled by common RET
YL	1, 2	1695-2690	1, 2, 3, 4
YR	3, 4	1695-2690	